

By Standard Number / 1910.134 App A - Fit Testing Procedures (Mandatory).

▪ Part Number:	1910
▪ Part Number Title:	Occupational Safety and Health Standards
▪ Subpart:	1910 Subpart I
▪ Subpart Title:	Personal Protective Equipment
▪ Standard Number:	1910.134 App A
▪ Title:	Fit Testing Procedures (Mandatory).
▪ GPO Source:	e-CFR

Appendix A to §1910.134—Fit Testing Procedures (Mandatory)

Part I. OSHA-Accepted Fit Test Protocols

A. Fit Testing Procedures—General Requirements

The employer shall conduct fit testing using the following procedures. The requirements in this appendix apply to a

1. The test subject shall be allowed to pick the most acceptable respirator from a sufficient number of respirator models. The respirator that most correctly fits, the user.
2. Prior to the selection process, the test subject shall be shown how to put on a respirator, how it should be positioned, and how to achieve an acceptable fit. A mirror shall be available to assist the subject in evaluating the fit and positioning of the respirator. Training on respirator use, because it is only a review.
3. The test subject shall be informed that he/she is being asked to select the respirator that provides the most acceptable fit, and if fitted and used properly, will provide adequate protection.
4. The test subject shall be instructed to hold each chosen facepiece up to the face and eliminate those that obviously do not fit.
5. The more acceptable facepieces are noted in case the one selected proves unacceptable; the most comfortable facepiece is noted. Assistance in assessing comfort can be given by discussing the points in the following item A.6. If the test subject shall be directed to don the mask several times and to adjust the straps each time to become adept at setting the mask.
6. Assessment of comfort shall include a review of the following points with the test subject and allowing the test subject to express any concerns.
 - (a) Position of the mask on the nose
 - (b) Room for eye protection
 - (c) Room to talk
 - (d) Position of mask on face and cheeks

7. The following criteria shall be used to help determine the adequacy of the respirator fit:

- (a) Chin properly placed;
- (b) Adequate strap tension, not overly tightened;
- (c) Fit across nose bridge;
- (d) Respirator of proper size to span distance from nose to chin;
- (e) Tendency of respirator to slip;
- (f) Self-observation in mirror to evaluate fit and respirator position.

8. The test subject shall conduct a user seal check, either the negative and positive pressure seal checks described by the respirator manufacturer which provide equivalent protection to the procedures in appendix B-1. Before conducting the seal check, the test subject shall be told to seat the mask on the face by moving the head from side-to-side and up and down slowly while taking in a few breaths. The test subject shall be retested if the test subject fails the user seal check tests.

9. The test shall not be conducted if there is any hair growth between the skin and the facepiece sealing surface, or any facial hair which cross the respirator sealing surface. Any type of apparel which interferes with a satisfactory fit shall be altered or removed.

10. If a test subject exhibits difficulty in breathing during the tests, she or he shall be referred to a physician or other qualified person to determine whether the test subject can wear a respirator while performing her or his duties.

11. If the employee finds the fit of the respirator unacceptable, the test subject shall be given the opportunity to select a different respirator model or size.

12. Exercise regimen. Prior to the commencement of the fit test, the test subject shall be given a description of the exercise procedure. The description of the process shall include a description of the test exercises that the subject will be performing and the duration of the test in minutes before the start of the fit test.

13. The fit test shall be performed while the test subject is wearing any applicable safety equipment that may be worn with the respirator fit.

14. Test Exercises.

(a) Employers must perform the following test exercises for all fit testing methods prescribed in this appendix, except for the CNP qualitative fit testing protocols, the CNP quantitative fit testing protocol, and the CNP REDON quantitative fit testing protocol. For the CNP qualitative fit testing protocols, employers shall ensure that the test subjects (*i.e.*, employees) perform the exercise procedure specified in Part I.C.5(b) for elastomeric respirators, or the exercise procedure specified in Part I.C.5(b) for filtering facepiece respirators. Employers shall ensure that the test subjects perform the exercise procedure specified in Part I.C.6(b) of this appendix for the CNP quantitative fit testing protocol, or the exercise procedure specified in Part I.C.6(b) of this appendix for the CNP REDON quantitative fit testing protocol. For the remaining fit testing methods, employers shall ensure that the test subjects perform the exercise procedure in the following manner:

- (1) Normal breathing. In a normal standing position, without talking, the subject shall breathe normally.
- (2) Deep breathing. In a normal standing position, the subject shall breathe slowly and deeply, taking caution so as not to strain.
- (3) Turning head side to side. Standing in place, the subject shall slowly turn his/her head from side to side between 45 and 90 degrees, pausing momentarily at each extreme so the subject can inhale at each side.
- (4) Moving head up and down. Standing in place, the subject shall slowly move his/her head up and down. The subject shall pause momentarily at the top and bottom of the movement.

looking toward the ceiling).

(5) Talking. The subject shall talk out loud slowly and loud enough so as to be heard clearly by the test conductor. 7
Passage, count backward from 100, or recite a memorized poem or song.

Rainbow Passage

When the sunlight strikes raindrops in the air, they act like a prism and form a rainbow. The rainbow is a division of long round arch, with its path high above, and its two ends apparently beyond the horizon. There is, according to legend, a pot of gold at the end of the rainbow. No one has ever finds it. When a man looks for something beyond reach, his friends say he is looking for the pot of gold at the end of the rainbow.

(6) Grimace. The test subject shall grimace by smiling or frowning. (This applies only to QNFT testing; it is not performed for QLFT testing.)

(7) Bending over. The test subject shall bend at the waist as if he/she were to touch his/her toes. Jogging in place is permitted for testing with shroud type QNFT or QLFT units that do not permit bending over at the waist.

(8) Normal breathing. Same as exercise (1).

(b) Each test exercise shall be performed for one minute except for the grimace exercise which shall be performed for 30 seconds. The test conductor shall monitor the subject's comfort and breathing apparatus throughout the test. If the test conductor regards the comfort of the respirator upon completion of the protocol. If it has become unacceptable, the test shall be stopped and the respirator adjusted. The test shall not be adjusted once the fit test exercises begin. Any adjustment voids the test, and the fit test must be repeated.

B. Qualitative Fit Test (QLFT) Protocols

1. General

(a) The employer shall ensure that persons administering QLFT are able to prepare test solutions, calibrate equipment, and ensure that test equipment is in proper working order.

(b) The employer shall ensure that QLFT equipment is kept clean and well maintained so as to operate within the parameters of the manufacturer's instructions.

2. Isoamyl Acetate Protocol

Note: This protocol is not appropriate to use for the fit testing of particulate respirators. If used to fit test particulate respirators, a vapor filter must be used.

(a) Odor Threshold Screening

Odor threshold screening, performed without wearing a respirator, is intended to determine if the individual tested can detect and identify odors.

(1) Three 1 liter glass jars with metal lids are required.

(2) Odor-free water (e.g., distilled or spring water) at approximately 25 °C (77 °F) shall be used for the solutions.

(3) The isoamyl acetate (IAA) (also known as isopentyl acetate) stock solution is prepared by adding 1 ml of pure IAA to 100 ml of water and shaking for 30 seconds. A new solution shall be prepared at least weekly.

(4) The screening test shall be conducted in a room separate from the room used for actual fit testing. The two rooms shall be separated by a closed door. The odor shall not become evident in the general room air where testing takes place.

(5) The odor test solution is prepared in a second jar by placing 0.4 ml of the stock solution into 500 ml of odor-free water, shaken for 30 seconds and allowed to stand for two to three minutes so that the IAA concentration above the liquid is uniform.

(6) A test blank shall be prepared in a third jar by adding 500 cc of odor-free water.

(7) The odor test and test blank jar lids shall be labeled (e.g., 1 and 2) for jar identification. Labels shall be placed on the jars and not on the lids to maintain the integrity of the test.

(8) The following instruction shall be typed on a card and placed on the table in front of the two test jars (i.e., 1 and 2): "The two bottles in front of you contain water. One of these bottles also contains banana oil. Then shake each bottle for two seconds. Unscrew the lid of each bottle, one at a time, and sniff at the mouth of the bottle containing the banana oil."

(9) The mixtures used in the IAA odor detection test shall be prepared in an area separate from where the test is performed.

(10) If the test subject is unable to correctly identify the jar containing the odor test solution, the IAA qualitative fit test is failed.

(11) If the test subject correctly identifies the jar containing the odor test solution, the test subject may proceed to the next test.

(b) Isoamyl Acetate Fit Test

(1) The fit test chamber shall be a clear 55-gallon drum liner suspended inverted over a 2-foot diameter frame so that the subject's head is in the center of the chamber. If no drum liner is available, a similar chamber shall be constructed using plastic sheeting. The inside of the chamber shall be lined with a material that will not absorb the odor of IAA.

(2) Each respirator used for the fitting and fit testing shall be equipped with organic vapor cartridges or offer protection against the odor of IAA.

(3) After selecting, donning, and properly adjusting a respirator, the test subject shall wear it to the fit testing room. The room shall be well-ventilated, as by an exhaust fan or lab hood, to prevent the buildup of IAA concentration above the threshold screening and respirator selection, and shall be well-ventilated, as by an exhaust fan or lab hood, to prevent the buildup of IAA concentration above the threshold screening and respirator selection.

(4) A copy of the test exercises and any prepared text from which the subject is to read shall be taped to the inside of the chamber.

(5) Upon entering the test chamber, the test subject shall be given a 6-inch by 5-inch piece of paper towel, or other material, saturated with 0.75 ml of pure IAA. The test subject shall hang the wet towel on the hook at the top of the chamber. An IAA test atmosphere shall be generated by the evaporation of IAA from the towel provided it has been demonstrated that the alternative IAA source will generate an IAA test atmosphere with a concentration of at least 10 ppm.

(6) Allow two minutes for the IAA test concentration to stabilize before starting the fit test exercises. This would be followed by a verbal explanation of the test, the importance of his/her cooperation, and the purpose for the test exercises; or to demonstrate some of the test exercises.

(7) If at any time during the test, the subject detects the banana-like odor of IAA, the test is failed. The subject shall leave the chamber and the test shall be terminated. The subject shall avoid olfactory fatigue.

(8) If the test is failed, the subject shall return to the selection room and remove the respirator. The test subject shall remove the respirator, return to the test area and again begin the fit test procedure described in (b) (1) through (7) above. The procedure shall be repeated until the test is passed. Should the odor sensitivity test be failed, the subject shall wait at least 5 minutes before retesting. Odor sensitivity shall be tested before the fit test.

(9) If the subject passes the test, the efficiency of the test procedure shall be demonstrated by having the subject breathe through the respirator in the chamber.

(10) When the test subject leaves the chamber, the subject shall remove the saturated towel and return it to the person conducting the test. The used towels shall be kept in a self-sealing plastic bag to prevent the odor of IAA from building up in the chamber during subsequent tests.

concentration buildup in the chamber during subsequent tests. The used towers shall be kept in a self-sealing plastic bag.

3. Saccharin Solution Aerosol Protocol

The entire screening and testing procedure shall be explained to the test subject prior to the conduct of the screening and testing.

(a) Taste threshold screening. The saccharin taste threshold screening, performed without wearing a respirator, is intended to detect the taste of saccharin.

(1) During threshold screening as well as during fit testing, subjects shall wear an enclosure about the head and shoulders with at least the front portion clear and that allows free movements of the head when a respirator is worn. An enclosure meeting the requirements of 29 CFR 1910.134 and # FT 15 combined, is adequate.

(2) The test enclosure shall have a 3/4 -inch (1.9 cm) hole in front of the test subject's nose and mouth area to accommodate the nebulizer.

(3) The test subject shall don the test enclosure. Throughout the threshold screening test, the test subject shall breathe through the enclosure. The subject is instructed to report when he/she detects a sweet taste.

(4) Using a DeVilbiss Model 40 Inhalation Medication Nebulizer or equivalent, the test conductor shall spray the threshold check solution away from the nose and mouth of the person. This nebulizer shall be clearly marked to distinguish it from the fit testing nebulizer.

(5) The threshold check solution is prepared by dissolving 0.83 gram of sodium saccharin USP in 100 ml of warm water (see (b)(5) below) in 100 ml of distilled water.

(6) To produce the aerosol, the nebulizer bulb is firmly squeezed so that it collapses completely, then released and allowed to return to its original shape.

(7) Ten squeezes are repeated rapidly and then the test subject is asked whether the saccharin can be tasted. If the test subject detects a sweet taste during the first ten squeezes, the screening test is completed. The taste threshold is noted as ten regardless of the number of squeezes required.

(8) If the first response is negative, ten more squeezes are repeated rapidly and the test subject is again asked whether a sweet taste is detected. If the test subject detects a sweet taste during the second ten squeezes, the screening test is completed. The taste threshold is noted as twenty regardless of the number of squeezes required.

(9) If the second response is negative, ten more squeezes are repeated rapidly and the test subject is again asked whether a sweet taste is detected. If the test subject detects a sweet taste during the third set of ten squeezes, the screening test is completed. The taste threshold is noted as thirty regardless of the number of squeezes required.

(10) The test conductor will take note of the number of squeezes required to solicit a taste response.

(11) If the saccharin is not tasted after 30 squeezes (step 10), the test subject is unable to taste saccharin and may not wear the enclosure for fit testing. Note to paragraph 3(a): If the test subject eats or drinks something sweet before the screening test, he/she may be required to wait 15 minutes before testing.

(12) If a taste response is elicited, the test subject shall be asked to take note of the taste for reference in the fit testing procedure.

(13) Correct use of the nebulizer means that approximately 1 ml of liquid is used at a time in the nebulizer body.

(14) The nebulizer shall be thoroughly rinsed in water, shaken dry, and refilled at least each morning and afternoon.

(b) Saccharin solution aerosol fit test procedure.

(1) The test subject may not eat, drink (except plain water), smoke, or chew gum for 15 minutes before the test.

(2) The fit test uses the same enclosure described in 3. (a) above.

- (3) The test subject shall don the enclosure while wearing the respirator selected in section I. A. of this appendix. The particulate filter(s).
- (4) A second DeVilbiss Model 40 Inhalation Medication Nebulizer or equivalent is used to spray the fit test solution to distinguish it from the screening test solution nebulizer.
- (5) The fit test solution is prepared by adding 83 grams of sodium saccharin to 100 ml of warm water.
- (6) As before, the test subject shall breathe through the slightly open mouth with tongue extended, and report if he/she detects a taste.
- (7) The nebulizer is inserted into the hole in the front of the enclosure and an initial concentration of saccharin fit test solution is generated by 10 to 30 squeezes (either 10, 20 or 30 squeezes) based on the number of squeezes required to elicit a taste response as required.
- (8) After generating the aerosol, the test subject shall be instructed to perform the exercises in section I. A. 14. of this appendix.
- (9) Every 30 seconds the aerosol concentration shall be replenished using one half the original number of squeezes.
- (10) The test subject shall indicate to the test conductor if at any time during the fit test the taste of saccharin is detected. If the test is passed.
- (11) If the taste of saccharin is detected, the fit is deemed unsatisfactory and the test is failed. A different respirator model shall be used for threshold screening and fit testing).
- (12) Since the nebulizer has a tendency to clog during use, the test operator must make periodic checks of the nebulizer. At the end of the test session, the test is invalid.

4. Bitrex™ (Denatonium Benzoate) Solution Aerosol Qualitative Fit Test

The Bitrex™ (Denatonium benzoate) solution aerosol QLFT protocol uses the published saccharin test protocol but replaces it with Bitrex as a taste aversion agent in household liquids which children should not be drinking and is endorsed by the American Association of Poison Control Centers. The entire screening and testing procedure shall be explained to the test subject.

(a) Taste Threshold Screening.

The Bitrex taste threshold screening, performed without wearing a respirator, is intended to determine whether the test subject can detect a bitter taste.

- (1) During threshold screening as well as during fit testing, subjects shall wear an enclosure about the head and shoulders that is at least 14 inches (35.6 cm) tall. The front portion of the enclosure shall be clear from the respirator and allow free movement of the head. A substantially similar to the 3M hood assembly, parts # FT 14 and # FT 15 combined, is adequate.
- (2) The test enclosure shall have a 3/4 inch (1.9 cm) hole in front of the test subject's nose and mouth area to accommodate the nebulizer.
- (3) The test subject shall don the test enclosure. Throughout the threshold screening test, the test subject shall breathe through the mouth with tongue extended. The subject is instructed to report when he/she detects a bitter taste.
- (4) Using a DeVilbiss Model 40 Inhalation Medication Nebulizer or equivalent, the test conductor shall spray the Threshold Check Solution. The nebulizer shall be clearly marked to distinguish it from the fit test solution nebulizer.
- (5) The Threshold Check Solution is prepared by adding 13.5 milligrams of Bitrex to 100 ml of 5% salt (NaCl) solution.
- (6) To produce the aerosol, the nebulizer bulb is firmly squeezed so that the bulb collapses completely and is then released.

- (6) To produce the aerosol, the nebulizer bulb is firmly squeezed so that the bulb collapses completely, and is then released.
- (7) An initial ten squeezes are repeated rapidly and then the test subject is asked whether the Bitrex can be tasted. If the test subject can taste the Bitrex after ten squeezes, the screening test is completed. The taste threshold is noted as ten regardless of the number of squeezes.
- (8) If the first response is negative, ten more squeezes are repeated rapidly and the test subject is again asked whether the Bitrex can be tasted. If the test subject can taste the Bitrex during the second ten squeezes, the screening test is completed. The taste threshold is noted as twenty regardless of the number of squeezes.
- (9) If the second response is negative, ten more squeezes are repeated rapidly and the test subject is again asked whether the Bitrex can be tasted. If the test subject can taste the Bitrex during the third set of ten squeezes, the screening test is completed. The taste threshold is noted as thirty regardless of the number of squeezes.
- (10) The test conductor will take note of the number of squeezes required to solicit a taste response.
- (11) If the Bitrex is not tasted after 30 squeezes (step 10), the test subject is unable to taste Bitrex and may not perform the fit test.
- (12) If a taste response is elicited, the test subject shall be asked to take note of the taste for reference in the fit test.
- (13) Correct use of the nebulizer means that approximately 1 ml of liquid is used at a time in the nebulizer body.
- (14) The nebulizer shall be thoroughly rinsed in water, shaken to dry, and refilled at least each morning and afternoon.
- (b) Bitrex Solution Aerosol Fit Test Procedure.

- (1) The test subject may not eat, drink (except plain water), smoke, or chew gum for 15 minutes before the test.
- (2) The fit test uses the same enclosure as that described in 4. (a) above.
- (3) The test subject shall don the enclosure while wearing the respirator selected according to section I. A. of this appendix with any type particulate filter(s).
- (4) A second DeVilbiss Model 40 Inhalation Medication Nebulizer or equivalent is used to spray the fit test solution in the enclosure to distinguish it from the screening test solution nebulizer.
- (5) The fit test solution is prepared by adding 337.5 mg of Bitrex to 200 ml of a 5% salt (NaCl) solution in warm water.
- (6) As before, the test subject shall breathe through his or her slightly open mouth with tongue extended, and be instructed to perform the exercises in section I. A. 14. of this appendix.
- (7) The nebulizer is inserted into the hole in the front of the enclosure and an initial concentration of the fit test solution is generated by ten squeezes (either 10, 20 or 30 squeezes) based on the number of squeezes required to elicit a taste response as noted in step 10.
- (8) After generating the aerosol, the test subject shall be instructed to perform the exercises in section I. A. 14. of this appendix.
- (9) Every 30 seconds the aerosol concentration shall be replenished using one half the number of squeezes used in step 7.
- (10) The test subject shall indicate to the test conductor if at any time during the fit test the taste of Bitrex is detected. If the taste of Bitrex is detected, the fit test is failed.
- (11) If the taste of Bitrex is detected, the fit is deemed unsatisfactory and the test is failed. A different respirator shall be used for the threshold screening and fit testing).

5. Irritant Smoke (Stannic Chloride) Protocol

This qualitative fit test uses a person's response to the irritating chemicals released in the "smoke" produced by a test aerosol generator.

(a) General Requirements and Precautions

- (1) The respirator to be tested shall be equipped with high efficiency particulate air (HEPA) or P100 series filter(s).
- (2) Only stannic chloride smoke tubes shall be used for this protocol.
- (3) No form of test enclosure or hood for the test subject shall be used.
- (4) The smoke can be irritating to the eyes, lungs, and nasal passages. The test conductor shall take precautions to prevent irritation. Sensitivity varies, and certain individuals may respond to a greater degree to irritant smoke. Care shall be taken when conducting the test to determine whether the test subject can detect irritant smoke to use only the minimum amount of smoke necessary to elicit a response.
- (5) The fit test shall be performed in an area with adequate ventilation to prevent exposure of the person conducting the test to the test atmosphere.

(b) Sensitivity Screening Check

The person to be tested must demonstrate his or her ability to detect a weak concentration of the irritant smoke.

- (1) The test operator shall break both ends of a ventilation smoke tube containing stannic chloride, and attach one end to a flowmeter set at one milliliter per minute, or an aspirator squeeze bulb. The test operator shall cover the other end of the smoke tube with the thumb. The jagged end of the smoke tube shall be held in the mouth of the test subject.
- (2) The test operator shall advise the test subject that the smoke can be irritating to the eyes, lungs, and nasal passages before the test is performed.
- (3) The test subject shall be allowed to smell a weak concentration of the irritant smoke before the respirator is donned. The test operator shall determine if he/she can detect the irritating properties of the smoke. The test operator shall carefully direct a small stream of smoke to determine that he/she can detect it.

(c) Irritant Smoke Fit Test Procedure

- (1) The person being fit tested shall don the respirator without assistance, and perform the required user seal check.
- (2) The test subject shall be instructed to keep his/her eyes closed.
- (3) The test operator shall direct the stream of irritant smoke from the smoke tube toward the faceseat area of the respirator. The test operator shall begin at least 12 inches from the facepiece and move the smoke stream around the whole perimeter of the mask, moving to within six inches of the respirator.
- (4) If the person being tested has not had an involuntary response and/or detected the irritant smoke, proceed with the test.
- (5) The exercises identified in section I.A. 14. of this appendix shall be performed by the test subject while the respirator is worn around the perimeter of the respirator at a distance of six inches.
- (6) If the person being fit tested reports detecting the irritant smoke at any time, the test is failed. The person being tested shall not repeat the procedure.
- (7) Each test subject passing the irritant smoke test without evidence of a response (involuntary cough, irritation) shall be retested. The test operator shall direct a small stream of smoke from the same smoke tube used during the fit test, once the respirator has been removed, to determine whether the test subject's response shall void the fit test.

(8) If a response is produced during this second sensitivity check, then the fit test is passed.

C. Quantitative Fit Test (QNFT) Protocols

The following quantitative fit testing procedures have been demonstrated to be acceptable: Quantitative fit testing using polyethylene glycol 400 [PEG 400], di-2-ethyl hexyl sebacate [DEHS], or sodium chloride) generated in a test chamber; Quantitative fit testing using ambient aerosol as the test agent and appropriate instrumentation (condensation); Quantitative fit testing using controlled negative pressure and appropriate instrumentation to measure the volumetric leak rate of a

1. General

(a) The employer shall ensure that persons administering QNFT are able to calibrate equipment and perform tests properly. The employer shall ensure that test equipment is in proper working order.

(b) The employer shall ensure that QNFT equipment is kept clean, and is maintained and calibrated according to the manufacturer's instructions for which it was designed.

2. Generated Aerosol Quantitative Fit Testing Procedures

(a) Apparatus.

(1) Instrumentation. Aerosol generation, dilution, and measurement systems using particulates (corn oil, polyethylene glycol 400, or sodium chloride) as test aerosols shall be used for quantitative fit testing.

(2) Test chamber. The test chamber shall be large enough to permit all test subjects to perform freely all required exercises. The test chamber shall be equipped and constructed so that the test agent is effectively mixed throughout the chamber.

(3) When testing air-purifying respirators, the normal filter or cartridge element shall be replaced with a high efficiency particulate respirator of the same manufacturer.

(4) The sampling instrument shall be selected so that a computer record or strip chart record may be made of the test results for each inspiration and expiration at fit factors of at least 2,000. Integrators or computers that integrate the amount of exercise may be used provided a record of the readings is made.

(5) The combination of substitute air-purifying elements, test agent and test agent concentration shall be such that the exposure limit for the test agent at any time during the testing process, based upon the length of the exposure and the concentration of the test agent, shall not be exceeded.

(6) The sampling port on the test specimen respirator shall be placed and constructed so that no leakage occurs and no air flow is allowed into the sampling line at all times, and there is no interference with the fit or performance of the respirator. The sampling port shall be used so that the air sample is drawn from the breathing zone of the test subject, midway between the nose and mouth, at least 1/4 inch.

(7) The test setup shall permit the person administering the test to observe the test subject inside the chamber during the test.

(8) The equipment generating the test atmosphere shall maintain the concentration of test agent constant to within ±5% of the test agent concentration.

(9) The time lag (interval between an event and the recording of the event on the strip chart or computer or integrator) shall be less than 1 second between the occurrence of an event and its being recorded.

----- the concentration of an agent and is being recorded.

(10) The sampling line tubing for the test chamber atmosphere and for the respirator sampling port shall be of equal length and the diameters shall be equal.

(11) The exhaust flow from the test chamber shall pass through an appropriate filter (i.e., high efficiency particulate filter).

(12) When sodium chloride aerosol is used, the relative humidity inside the test chamber shall not exceed 50 percent.

(13) The limitations of instrument detection shall be taken into account when determining the fit factor.

(14) Test respirators shall be maintained in proper working order and be inspected regularly for deficiencies such as:

(b) Procedural Requirements.

(1) When performing the initial user seal check using a positive or negative pressure check, the sampling line shall be connected to the test chamber atmosphere and either of these pressure checks.

(2) The use of an abbreviated screening QLFT test is optional. Such a test may be utilized in order to quickly identify poor fitting respirators, perform a positive pressure test and reduce the amount of QNFT time. The use of the CNC QNFT instrument in the count mode is an acceptable method to quickly identify and eliminate poor fitting respirators before going on to perform a full QNFT.

(3) A reasonably stable test agent concentration shall be measured in the test chamber prior to testing. For canopy tests, the test agent's stability may be established after the test subject has entered the test environment.

(4) Immediately after the subject enters the test chamber, the test agent concentration inside the respirator shall be at least 5 percent for a half mask or 1 percent for a full facepiece respirator.

(5) A stable test agent concentration shall be obtained prior to the actual start of testing.

(6) Respirator restraining straps shall not be over-tightened for testing. The straps shall be adjusted by the wearer to achieve a comfortable fit typical of normal use. The respirator shall not be adjusted once the fit test exercises begin.

(7) The test shall be terminated whenever any single peak penetration exceeds 5 percent for half masks and 1 percent for full facepiece respirators. The test shall be refitted and retested.

(8) Calculation of fit factors.

(i) The fit factor shall be determined for the quantitative fit test by taking the ratio of the average chamber concentration to the average concentration inside the respirator for each test exercise except the grimace exercise.

(ii) The average test chamber concentration shall be calculated as the arithmetic average of the concentration measured before and after each exercise or the true average measured continuously.

(iii) The concentration of the challenge agent inside the respirator shall be determined by one of the following methods:

(A) Average peak penetration method means the method of determining test agent penetration into the respirator by measuring the peak penetration. Peak penetration is determined by an average of the peak heights on the graph or by computer integration, for each exercise. The average peak penetration for each exercise will also be considered to meet the requirements of this method.

(B) Maximum peak penetration method means the method of determining test agent penetration in the respirator by measuring the maximum peak penetration for a given exercise is taken to be representative of average penetration into the respirator for that exercise.

(C) Integration by calculation of the area under the individual peak for each exercise except the grimace exercise. The

(C) integration by calculation of the area under the individual peak for each exercise except the gymnae exercise. 1

(D) The calculation of the overall fit factor using individual exercise fit factors involves first converting the exercise fi then converting that result back to a fit factor. This procedure is described in the following equation:

$$\text{Overall Fit Factor} = \frac{\text{Number of exercises}}{1/ff_1 + 1/ff_2 + 1/ff_3 + 1/ff_4 + 1/ff_5 + 1/ff_6 + 1/ff_7 + 1/ff_8}$$

View or download PDF

Where ff1, ff2, ff3, etc. are the fit factors for exercises 1, 2, 3, etc.

(9) The test subject shall not be permitted to wear a half mask or quarter facepiece respirator unless a minimum fit minimum fit factor of 500 is obtained.

(10) Filters used for quantitative fit testing shall be replaced whenever increased breathing resistance is encountere media.

3. Ambient aerosol condensation nuclei counter (CNC) quantitativ

The ambient aerosol condensation nuclei counter (CNC) quantitative fit testing (PortaCount®) protocol quantitative respirator is only used for quantitative fit tests. A probed respirator has a special sampling device, installed on the r mask. A probed respirator is required for each make, style, model, and size that the employer uses and can be obt CNC instrument manufacturer, TSI Incorporated, also provides probe attachments (TSI mask sampling adapters) th fit factor pass level of at least 100 is necessary for a half-mask respirator (elastomeric or filtering facepiece), and a facepiece elastomeric respirator. The entire screening and testing procedure shall be explained to the test subject p

(a) PortaCount® Fit Test Requirements. (1) Check the respirator to make sure the sampling probe and line are prop with a particulate filter capable of preventing significant penetration by the ambient particles used for the fit test (e. particulate filter) per manufacturer's instruction.

(2) Instruct the person to be tested to don the respirator for five minutes before the fit test starts. This purges the ar wearer to make certain the respirator is comfortable. This individual shall already have been trained on how to wear

(3) Check the following conditions for the adequacy of the respirator fit: Chin properly placed; Adequate strap tensi proper size to span distance from nose to chin; Tendency of the respirator to slip; Self-observation in a mirror to ev

(4) Have the person wearing the respirator do a user seal check. If leakage is detected, determine the cause. If leak same model respirator, or another model of respirator.

(5) Follow the manufacturer's instructions for operating the PortaCount® and proceed with the test.

(6) The test subject shall be instructed to perform the exercises in section I. A. 14. of this appendix.

(7) After the test exercises, the test subject shall be questioned by the test conductor regarding the comfort of the unacceptable, another model of respirator shall be tried.

(b) PortaCount® Test Instrument.

(1) The PortaCount® will automatically stop and calculate the overall fit factor for the entire set of exercises. The ov indicate whether or not the test was successful. If the test was a Pass, the fit test is over.

- (2) Since the pass or fail criterion of the PortaCount® is user programmable, the test operator shall ensure that the respirator performance in this Appendix.
- (3) A record of the test needs to be kept on file, assuming the fit test was successful. The record must contain the t size of respirator used; and date tested.

4. Modified ambient aerosol condensation nuclei counter (CNC) quantitative fit testing protocol fo

- (a) When administering this protocol to test subjects, employers shall comply with the requirements specified in Pa counter (CNC) quantitative fit testing protocol), except they shall use the test exercises described below in paragra section I.C.3(a)(6) of this appendix.
- (b) Employers shall ensure that each test subject being fit tested using this protocol follows the exercise and durati in Table A-1 of this appendix.

Table A-1 -- Modified Ambient Aerosol CNC Quantitative Fit Testing Protocol for Full Facep

Exercises ¹	Exercise procedure
Bending Over	The test subject shall bend at the waist, as if going to touch his/her toes for 5 seconds and inhale 2 times at the bottom ² .
Jogging-in-Place	The test subject shall jog in place comfortably for 30 seconds
Head Side-to-Side	The test subject shall stand in place, slowly turning his/her head from side to 30 seconds and inhale 2 times at each extreme ² .
Head Up-and-Down	The test subject shall stand in place, slowly moving his/her head up and down seconds and inhale 2 times at each extreme ² .

¹Exercises are listed in the order in which they are to be administered.

²It is optional for test subjects to take additional breaths at other times during this exercise.

5. Modified ambient aerosol condensation nuclei counter (CNC) quantitative fit testing

- (a) When administering this protocol to test subjects, employers shall comply with the requirements specified in Pa counter (CNC) quantitative fit testing protocol), except they shall use the test exercises described below in paragra section I.C.3(a)(6) of this appendix.
- (b) Employers shall ensure that each test subject being fit tested using this protocol follows the exercise and durati in Table A-2 of this appendix

TABLE A-2 — MODIFIED AMBIENT AEROSAL CNC QUANTITATIVE FIT TESTING PROTOC

Exercises ¹	Exercise
------------------------	----------

	procedure
Bending Over	The test subject shall bend at the waist, as if going to touch his/her toes for 5 seconds and inhale 2 times at the bottom ² .
Talking	The test subject shall talk out loud slowly and loud enough so as to be heard by the test conductor for 30 seconds. He/she will either read from a prepared text as the Rainbow Passage, count backward from 100, or recite a memorized poem or song.
Head Side-to-Side	The test subject shall stand in place, slowly turning his/her head from side to side for 30 seconds and inhale 2 times at each extreme ² .
Head Up-and-Down	The test subject shall stand in place, slowly moving his/her head up and down for 30 seconds and inhale 2 times at each extreme ² .

¹Exercises are listed in the order in which they are to be administered.

²It is optional for test subjects to take additional breaths at other times during this exercise.

6. Controlled negative pressure (CNP) quantitative fit test

The CNP protocol provides an alternative to aerosol fit test methods. The CNP fit test method technology is based on the ability to generate and then maintain a constant negative pressure inside the facepiece. The rate of air exhaust is controlled by the respirator during the fit test. The level of pressure is selected to replicate the mean inspiratory pressure that causes the pressure held constant, air flow out of the respirator is equal to air flow into the respirator. Therefore, measurement of leakage through a temporarily sealed respirator constant yields a direct measure of leakage air flow into the respirator. The CNP fit test method for determining the facepiece fit for negative pressure respirators. The CNP instrument manufacturer OccuFit provides attachments (sampling manifolds) that replace the filter cartridges to permit fit testing in an employee's mouth and holds his/her breath, after which an air pump removes air from the respirator facepiece at a pre-selected rate. The leak rate through the facepiece, expressed as milliliters per minute. The quality and validity of the CNP fit tests are determined by the test pressure during the system measurement time of approximately five seconds. Instantaneous feedback is provided and used to determine test validity and quality. A minimum fit factor pass level of 100 is necessary for a half mask required for a full facepiece respirator. The entire screening and testing procedure shall be explained to the test subject.

(a) CNP Fit Test Requirements.

(1) The instrument shall have a non-adjustable test pressure of 15.0 mm water pressure.

(2) The CNP system defaults selected for test pressure shall be set at -15 mm of water (-0.58 inches of water) and used for performing fit tests.

Note: CNP systems have built-in capability to conduct fit testing that is specific to unique work rate, mask, and generator system default values, which were selected to represent respirator wear with medium cartridge resistance at a low-respirator fit.)

(3) The individual who conducts the CNP fit testing shall be thoroughly trained to perform the test.

(4) The respirator filter or cartridge needs to be replaced with the CNP test manifold. The inhalation valve downstream is propped open.

(5) The employer must train the test subject to hold his or her breath for at least 10 seconds.

(6) The test subject must don the test respirator without any assistance from the test administrator who is conducting the fit-test exercises begin. Any adjustment voids the test, and the test subject must repeat the fit test.

(7) The QNFT protocol shall be followed according to section I. C. 1. of this appendix with an exception for the CNP

(b) CNP Test Exercises.

(1) Normal breathing. In a normal standing position, without talking, the subject shall breathe normally for 1 minute. head straight ahead and hold his or her breath for 10 seconds during the test measurement.

(2) Deep breathing. In a normal standing position, the subject shall breathe slowly and deeply for 1 minute, being careful the subject shall hold his or her head straight ahead and hold his or her breath for 10 seconds during test measurement.

(3) Turning head side to side. Standing in place, the subject shall slowly turn his or her head from side to side between 45 and 90 degrees. The head shall be held at each extreme momentarily so the subject can inhale at each side. After the turning head side to side exercise, the subject shall hold his or her breath for 10 seconds during test measurement. Next, the subject needs to hold head full right and hold his or her breath for 10 seconds during test measurement.

(4) Moving head up and down. Standing in place, the subject shall slowly move his or her head up and down for 1 minute in a normal position (i.e., when looking toward the ceiling). After the moving head up and down exercise, the subject shall hold his or her head straight ahead and hold his or her breath for 10 seconds during test measurement. Next, the subject shall hold his or her head full down and hold his or her breath for 10 seconds during test measurement.

(5) Talking. The subject shall talk out loud slowly and loud enough so as to be heard clearly by the test conductor. 1. Recite the Lord's Prayer, count backward from 100, or recite a memorized poem or song for 1 minute. After the talking exercise, the subject shall hold his or her breath for 10 seconds during the test measurement.

(6) Grimace. The test subject shall grimace by smiling or frowning for 15 seconds.

(7) Bending Over. The test subject shall bend at the waist as if he or she were to touch his or her toes for 1 minute. In test environments such as shroud-type QNFT units that prohibit bending at the waist. After the bending over exercise, the subject shall hold his or her breath for 10 seconds during the test measurement.

(8) Normal Breathing. The test subject shall remove and re-don the respirator within a one-minute period. Then, in a normal standing position, the subject shall breathe normally for 1 minute. After the normal breathing exercise, the subject shall hold his or her head straight ahead and hold his or her breath for 10 seconds during test measurement. After the test exercises, the test subject shall be questioned by the test conductor regarding the comfort of the respirator. If the comfort becomes unacceptable, another model of a respirator shall be tried.

(c) CNP Test Instrument.

(1) The test instrument must have an effective audio-warning device, or a visual-warning device in the form of a screen. The test subject shall hold his or her breath during the test. The test must be terminated and restarted from the beginning when the test subject fails the test. The test subject then may be refitted and retested.

(2) A record of the test shall be kept on file, assuming the fit test was successful. The record must contain the test subject's name; the respirator used; and date tested.

7. Controlled negative pressure (CNP) REDON quantitative fit

- (a) When administering this protocol to test subjects, employers must comply with the requirements specified in paragraph (a) of part I.C.6 of this appendix, as well as use the test exercises described below in paragraph (b) of part I.C.6 of this appendix.
- (b) Employers must ensure that each test subject being fit tested using this protocol follows the exercise and measures described in Table A-3 of this appendix.

Table A-3—CNP REDON Quantitative Fit Testing Procedures

Exercises ¹	Exercise procedure
Facing Forward	Stand and breathe normally, without talking, for 30 seconds
Bending Over	Bend at the waist, as if going to touch his or her toes, for 30 seconds
Head Shaking	For about three seconds, shake head back and forth vigorously several times shouting
REDON 1	Remove the respirator mask, loosen all facepiece straps, and then redon the mask
REDON 2	Remove the respirator mask, loosen all facepiece straps, and then redon the mask again

¹Exercises are listed in the order in which they are to be administered.

- (c) After completing the test exercises, the test administrator must question each test subject regarding the comfort of the fit. If the fit is unacceptable, the employer must ensure that the test administrator repeats the protocol using another respirator.
- (d) Employers must determine the overall fit factor for each test subject by calculating the harmonic mean of the fit factors for each exercise.

Overall Fit Factor =
$$\frac{N}{\left[\frac{1}{FF_1} + \frac{1}{FF_2} + \dots + \frac{1}{FF_N} \right]}$$

[View or download PDF](#)

Where:

- N = The number of exercises;
- FF1 = The fit factor for the first exercise;
- FF2 = The fit factor for the second exercise; and
- FFN = The fit factor for the nth exercise.

1910.134 App A - Fit Testing Procedures (Mandatory). | Occupational Safety and Health Administration

- A. Any person may submit to OSHA an application for approval of a new fit test protocol. If the application meets the requirements of section 6(b)(7) of the OSH Act to determine whether to list the new protocol as an approved protocol in this appendix.
- B. The application must include a detailed description of the proposed new fit test protocol. This application must include:

1. A test report prepared by an independent government research laboratory (e.g., Lawrence Livermore National Laboratory for Standards and Technology) stating that the laboratory has tested the protocol and had found it to be accurate and reliable.

2. An article that has been published in a peer-reviewed industrial hygiene journal describing the protocol and explaining its reliability.
- C. If OSHA determines that additional information is required before the Agency commences a rulemaking proceeding, it must afford the applicant the opportunity to submit the supplemental information. Initiation of a rulemaking proceeding without supplemental information.

[63 FR 20098, April 23, 1998; 69 FR 46993, August 4, 2004]

UNITED STATES

DEPARTMENT OF LABOR

Occupational Safety & Health Administration	FEDERAL GOVERNMENT	OCCUPATIONAL SAFETY
200 Constitution Ave NW	White House	Frequently Asked Questions
Washington, DC 20210	Severe Storm and Flood Recovery Assistance	A - Z Index
☎ 800-321-6742 (OSHA)	Disaster Recovery Assistance	Freedom of Information Act
TTY	DisasterAssistance.gov	Read The OSHA Newsletter
www.OSHA.gov	USA.gov	Subscribe to the OSHA Newsletter
	No Fear Act Data	OSHA Publications
	U.S. Office of Special Counsel	Office of Inspector General